

| Item | Function Description |
|------|-------------------------------|
| a | Power LED |
| b | Charge Status LEDs |
| c | Gooseneck, Boundary Connector |
| d | DC Jack |
| e | Power Switch |
| f | Ethernet Port |
| g | Reset Button |

SHURE SBC450

