





PSM700 Frequency Chart Supplement



L2		
CHANNEL	GROUP 1 (MHz)	GROUP 2 (MHz)
0	632.200	661.800
1	633.150	660.850
2	634.825	659.175
3	638.375	655.625
4	639.000	655.000
5	641.300	652.700
6	646.150	647.850
7	653.625	640.375
8	654.925	639.075
9	658.150	635.850
A	659.625	643.025
B	661.575	649.650
C	645.325	644.350
D	635.975	651.250
E	648.675	659.125
F	650.725	661.375



L2		
CHANNEL	GROUP 1 (MHz)	GROUP 2 (MHz)
0	632.200	661.800
1	633.150	660.850
2	634.825	659.175
3	638.375	655.625
4	639.000	655.000
5	641.300	652.700
6	646.150	647.850
7	653.625	640.375
8	654.925	639.075
9	658.150	635.850
A	659.625	643.025
B	661.575	649.650
C	645.325	644.350
D	635.975	651.250
E	648.675	659.125
F	650.725	661.375